

bemodern

FIREPLACES & STOVES | BATHROOM FURNITURE

This light set requires a 3 amp plug to be fitted prior to connecting the components

If In Doubt Please Contact a Qualified Electrician

- Connect the white two pin plug to the brown two pin socket on the LED driver
- Connect one of the LED lights into one of the connections on the three way connector
- Connect the extension lead into one of the remaining two connections of the three way connector
- Finally connect the remaining LED light to the socket of the extension lead

TECHNICAL HELP AND ASSISTANCE WITH ANY MISSING COMPONENTS PLEASE CONTACT

BE MODERN LTD. CUSTOMER SERVICES

TEL: 0191 430 9001

FAX: 0191 430 9522